



# Tutorial on Packet Time Metrics

**Lee Cosart**

lee.cosart@microsemi.com

ITSF 2014



# Introduction

- Frequency transport
  - One-way: forward & reverse packet streams can be used separately
  - Asymmetry is irrelevant
  - Stable frequency needed
  - PRC (primary reference clock) needed
  - GNSS/GPS antenna cable compensation/calibration not needed
  - GSM frequency backhaul (50 ppb) is example technology
  
- Time transport
  - Two-way: forward & reverse packet streams used together
  - Asymmetry is critical
  - Stable time and frequency needed
  - PRTC (primary reference time clock) needed
  - GNSS/GPS antenna cable compensation/calibration needed
  - LTE-TDD time/phase (1.5  $\mu$ sec) is example technology

# Testing Time “Physical” vs. “Packet”

## ■ “1 PPS” (Single Point Measurement)


- Measurements are made at a single point – a single piece of equipment in a single location - a phase detector with reference - is needed




## ■ “Packet” (Dual Point Measurement)

- Measurements are constructed from packets time-stamped at two points – in general two pieces of equipment, each with a reference, at two different locations – are needed

	Timestamp A	Timestamp B
F	1286231440.883338640	1286231440.883338796
R	1286231441.506929352	1286231441.506929500
F	1286231441.883338640	1286231441.883338796
R	1286231442.506929352	1286231442.506929500
F	1286231442.883338640	1286231442.883338796
R	1286231443.506929352	1286231443.506929516




# Time Accuracy and Stability Requirements



Time Accuracy  
Time Error:  $\leq 100\text{ns}$


Time Stability  $\rightarrow$  TDEV

MTIE



MTIE is G.811 with 100 ns maximum  
TDEV is G.811 exactly

## Packet Network Limits



A: Time Error:  $\leq 100\text{ns}$

C: Time Error:  $\leq 1.1\mu\text{s}$

# Stability metrics for PDV

## ■ Packet Selection Processes

### 1) **Pre-processed:** packet selection step prior to calculation

- Example: **TDEV(PDVmin)** where *PDVmin* is a new sequence based on minimum searches on the original PDV sequence

### 2) **Integrated:** packet selection integrated into calculation

- Example: **minTDEV(PDV)**

## ■ Packet Selection Methods

- Minimum:  $x_{\min}(i) = \min[x_j] \text{ for } (i \leq j \leq i + n - 1)$

- Percentile:  $x'_{pct\_mean}(i) = \frac{1}{m} \sum_{j=0}^b x'_{j+i}$


- Band:  $x'_{band\_mean}(i) = \frac{1}{m} \sum_{j=a}^b x'_{j+i}$

- Cluster: 
$$x(n\tau_0) = \frac{\sum_{i=0}^{(K-1)} w((nK+i)\tau_p) \cdot \phi(n,i)}{\sum_{i=0}^{(K-1)} \phi(n,i)} \quad \phi(n,i) = \begin{cases} 1 & \text{for } |w(nK+i) - \alpha(n)| < \delta \\ 0 & \text{otherwise} \end{cases}$$

# Packet Selection Windows


## ■ Windows

- **Non-overlapping windows**  
(next window starts at prior window stop)
- **Skip-overlapping windows**  
(windows overlap but starting points skip over N samples)
- **Overlapping windows**  
(windows slide sample by sample)




- Packet Selection Approaches (e.g. selecting fastest packets)
  - Select X% fastest packets (e.g. 2%)
  - Select N fastest packets (e.g. 10 fastest packets in a window)
  - Select all packets faster than Y (e.g. all packets faster than 150 $\mu$ s)

# G.8260 Appendix I Metrics




**Pre-processed packet selection**



**Integrated packet selection**

G.8260(10)\_Fl.4



**Metrics including pre-filtering**

FPC, FPR, FPP: Floor Packet Count/Rate/Percent

**PDV metrics studying minimum floor delay packet population**

# Time Transport: Two-way metrics

## Packet Time Transport Metrics

*Normalized roundtrip:*  $r(n) = \left(\frac{1}{2}\right) \cdot [R(n) + F(n)]$

*Normalized offset:*  $\eta_2(n) = \left(\frac{1}{2}\right) \cdot [R(n) - F(n)]$

*xRoundtrip:*  $r'(n') = \left(\frac{1}{2}\right) \cdot [R'(n') + F'(n')]$

*xOffset:*  $\eta_2'(n') = \left(\frac{1}{2}\right) \cdot [R'(n') - F'(n')]$

*minOffset:*  $\eta_2^m(n) = \left(\frac{1}{2}\right) \cdot [R^m(n) - F^m(n)]$

*pctOffset:*  $\eta_2^p(n) = \left(\frac{1}{2}\right) \cdot [R^p(n) - F^p(n)]$

*clusterOffset:*  $\eta_2^c(n) = \left(\frac{1}{2}\right) \cdot [R^c(n) - F^c(n)]$

*xTDISP (min/pct/clst time dispersion):*  
xOffset {y} plotted against xRoundtrip {x} as a scatter plot

*xOffset statistics:* xOffset statistic such as mean, standard deviation, median, 95 percentile plotted as a function of time window tau

*Weighted average:*  $w(n) = [a \cdot F(n) + (1 - a) \cdot R(n)]$  where  $0 \leq a \leq 1$



# Time Transport: Two-way packet delay

## Forward Packet Delay Sequence

#Start: 2010/03/06 17:15:30

0.0000, 1.47E-6  
 0.1000, 1.54E-6  
 0.2000, 1.23E-6  
 0.3000, 1.40E-6  
 0.4000, 1.47E-6  
 0.5000, 1.51E-6

## Packet Delay Sequence Reverse

#Start: 2010/03/06 17:15:30

0.0000, 1.11E-6  
 0.1000, 1.09E-6  
 0.2000, 1.12E-6  
 0.3000, 1.13E-6  
 0.4000, 1.22E-6  
 0.5000, 1.05E-6

#Start: 2010/03/06 17:15:30

0.0000, 1.47E-6, 1.11E-6  
 0.1000, 1.54E-6, 1.09E-6  
 0.2000, 1.23E-6, 1.12E-6  
 0.3000, 1.40E-6, 1.13E-6  
 0.4000, 1.47E-6, 1.22E-6  
 0.5000, 1.51E-6, 1.05E-6

Two-way  
Data Set

Constructing  $f'$  and  $r'$   
from  $f$  and  $r$  with a 3-  
sample time window

Time(s)	$f(\mu s)$	$r(\mu s)$	$f'(\mu s)$	$r'(\mu s)$
0.0	1.47	1.11		
0.1	1.54	1.09	1.23	1.09
0.2	1.23	1.12		
0.3	1.40	1.13		
0.4	1.47	1.22	1.40	1.05
0.5	1.51	1.05		

Minimum Search  
Sequence

0.1	-0.07
0.4	-0.18


minOffset

$$\eta_2'(n') = \left(\frac{1}{2}\right) \cdot [R'(n') - F'(n')]$$

# Time Transport: Two-way metrics

## Forward/Reverse FPP

Symmetricon TimeMonitor Analyzer  
Floor Packet Percent: Window=200 s; Range=50.0 us; Floor=-54.3 us; Fmin; T=200 s; A=3200; N=382  
1 (blue): Fwd FPP; 2 (red): Rev FPP



### Comments:


- (1) Knowledge of asymmetry and latency in both directions is critical
- (2) Offset is a fundamental two-way calculation
- (3) Ideal fwd/rev packet: floor  
Ideal offset: zero

### Approaches:

- (1) Based on both one-way sequences
- (2) Based on a single sequence constructed from both one-way sequences (e.g. offset)

## Two-way MAFE (MAFE of minOffset)

Symmetricon TimeMonitor Analyzer (file=probe-2008\_09\_04-12\_54d.tpk)  
MAFE; Fo=10.00 MHz; Fs=100.6 MHz; 2008/09/04; 16:55:05




# Offset ↔ Network Asymmetry


## Asymmetry in Wireless Backhaul

(Ethernet wireless backhaul asymmetry and IEEE 1588 slave 1PPS under these asymmetrical network conditions)

Symmetricon TimeMonitor Analyzer; Ethernet Wireless Backhaul; 2009/04/28; 11:37:01



Min  
TDISP



1588  
Slave  
1 PPS  
vs. GPS

# Network Asymmetry

## 150 km fiber SONET transport


(Offset is 20.4  $\mu$ sec which represents the 40.8  $\mu$ sec difference between forward and reverse one-way latencies)

Symmetricon TimeMonitor Analyzer (file=OC192\_baseline\_8Hz\_5d-2014\_04\_17--20\_51e.twy)  
Phase deviation in units of time; Fs=7.990 Hz; Fo=10.000000 MHz; 2014/04/17 20:52:41  
Two-Way Normalized Offset Phase; Samples: 799017; Initial phase offset: 20.3640 usec  
OC192 Baseline Measurement; MasterUUID: 00B0AEFFFE029249; MasterIP: 10.0.1.11; ProbeUU  
21.0  
usec

21.0  
usec

100  
nsec/div

20.0  
usec



Rev: 2.014 ms

Fwd: 1.974 ms

# Conclusions

- Packet time transport measurements require common time scale reference at both ends of the network being studied (GNSS at both ends is a way to do this)
- Asymmetry is everywhere, asymmetry is invisible to the IEEE 1588 protocol, thus asymmetry has a direct bearing on the ability to transport time precisely
- The “offset” calculation is a direct measure of asymmetry
- There are two ways to assess time transport: (1) measuring a 1PPS reference at the node being studied and (2) measuring a packet signal at the node being studied
- Packet metrics for time transport must use both forward and reverse streams together rather than separately as is the case for frequency transport
- Packet metrics for time transport can make use of much of the methodology used for packet frequency transport metrics

# Thank You

---

**Lee Cosart**

Senior Technologist

[Lee.Cosart@microsemi.com](mailto:Lee.Cosart@microsemi.com)

Phone: +1-408-428-6950